


Euroslider® Door Cavity Construction Installation Details

EUROSLIDER® WINDOW & DOOR SYSTEMS

EUROSLIDER® - HEAD DETAIL



Method:

- 1) Rip legs of angle to suit cladding thickness. Screw fix to front face of lintel.
- 2) Screw fix similar ripped angles to jamb stud work as per notes.
- 3) Fix selected support angle and sill flashing in place. Locate appropriate packers.
- 4) Position unit into trimmed opening and 'tack off' through liners.
- 5) Screw fix off remainder of unit through reveals as detailed.


Note:

Use angles as shown prior to the building cladding being in place.


Refer the weather tightness details on the appropriate claddings page in the WANZ Manual.

Some thinner cavity claddings may need the wall framing packed to fit the long reach of the stacker door frame into the overall wall thickness.

EUROSLIDER® SILL DETAIL



EUROSLIDER® REBATED SILL DETAIL



EUROSLIDER® JAMB DETAIL

